



Collection de Mediterania

INSTALLATION

Once your flooring product has been procured, we suggest you contract with a professional wood flooring installer to install your floor.

The success of your installation will rely heavily on proper jobsite conditions being met prior to the floors installation. Your Collection de Mediterania floor should not be brought on site until all windows and doors are installed and all drywall and paint or texturing is completed. Once on-site, your floor should be stacked in the area it is to be installed, please allow 14 days for proper acclimatization. Your flooring product should never be stored in an unheated area, or below grade.

All N.W.F.A. installation guidelines should be adhered to when installing your floor.

All plank flooring should be glued and nailed. We recommend a urethane based wood floor adhesive and a proper nailing schedule, every four to six inches should be sufficient.

All engineered flooring can be installed via either a floating method, or nailed, or glued directly to the substrate, application permitting.

All pneumatic or manual blind nailers should have a layer of tape over their plates; this will diminish the opportunity for scratches on the finished product.

The floor should be swept and vacuumed after installation, with any residual mastic removed using Bostik's Ultimate Remover.

Your Collection de Mediterania floor is unique; knots, distressment, cracks and dents are all part of your floors character. Some boards may be deemed unsightly, place them in inconspicuous spots. Consult with your installer prior to final installation.