



BonaTech Prep Recoating Adhesion System

Recommended BonKemi Recoating Procedure for Forest Accents “City Plank” Prefinished UV Aluminum Oxide flooring

➤ **Clean the floor thoroughly**

1. Vacuum or sweep floor to remove loose dirt and grit.
2. **DO NOT USE THIS RECOATING PROCEDURE OVER ANY FLOOR THAT HAS BEEN WAXED OR OILED.** If unsure, wipe a small section of the floor with a clean, white rag dampened with mineral spirits. If a wax residue appears as a shiny glaze on the rag, **DO NOT RECOAT WITH FINISH.** BonaKemi **DOES NOT GUARANTEE ADHESION OF FINISH OVER WAX OR OIL RESIDUES.**
3. Use BonaTech® Prep as a spray buff solution with a standard speed (175 rpm) buffer using a Bona® Conditioning Pad. This cleans the floor to ensure any foreign material is removed, as well as conditions and prepares the old finish to optimize adhesion of the new coat of finish.
4. **REMOVE ALL RESIDUES IMMEDIATELY USING A BONA® MOP OR A WRUNG-OUT COTTON TACK RAG DAMPENED WITH BONATECH® PREP.**

➤ **Abrade the floor once it has dried**

5. Use *two* Bona® Conditioning Pads (one driving the other) so that the pad more effectively contours to the surface of the flooring. This will optimize abrasion of the edges next to any overwood and in the grain pattern, and ensure good adhesion of the finish topcoat. Beveled edges and any visibly unabraded areas should be cleaned and abraded by hand.
6. Tack the floor again to remove dust using a Bona® Mop or a wrung-out cotton tack rag dampened with BonaTech® Prep.

➤ **Apply finish**

7. Immediately apply one of the recommended BonaKemi finishes following the label directions.

Recommended BonaKemi Finish: BonaTech TRAFFIC™ or Pacific Strong™

Note: At this time we would recommend using only BonaTech TRAFFIC™ or Pacific Strong™ as recoat finishes for *Ua Wood Floor* UV Aluminum Oxide flooring. This allows for the full range of sheen levels from gloss to “commercial satin”.